



CLASSIC


7 LEGO.com

10695



WARNING: CHOKING HAZARD.
Small parts. Not for children under 3 years.







AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.

Contient des petites pièces. Ne convient pas aux enfants de moins de 3 ans.



ADVERTENCIA: PELIGRO DE ASFIXIA.

No recomendado para niños menores de 3 años. Contiene piezas pequeñas.



LEGO.com/brickseparator





Easy Building
Construction facile
Construcción fácil



Medium Building
Construction intermédiaire
Construcción intermedia



Advanced Building
Construction avancée
Construcción avanzada



LEGO.com/classic

Page/pag.

43



Page/pag.

13



Page/pag.

6





Page/pag.
26





1x



1x

1





2x


2




3x

3





4




5





2x

6



1x



1x

7





1x



1x

8



1x



1x

9





1x



1x

10



3x



3x

11





1x



1x



2x

12

1




2





3






1





2x


2





2x

3



2x

4






2x



1x

5






2x




2x

6



2x


7








2x

8







9



10






1x




2x

11







12



13






2x



1x

14






1x





1x

15



2x


16





2x

17




4x



1x

18





4x



4x

19





1x



1x

1





1x

2



1x



2x

3





1x



2x


4





1x

5



1x

6





2x



1x

7






1x



1x

8



2x

9





1x

10





1x



1x

11




2x

12







13





2x

14



2x

15





1x

16





1x

17



1x



1x

18





2x


19





2x

20



1x



2x

21





1x

1



2x

2





1x

3




1x

4





5





1






1x



1x

2



1x

3





1x



1x

4



1x

5





2x

6





1x





1x


7





8





9


1




2



3







More Ideas Online:
LEGO.com/classic

Plus d'idées en ligne :
Más ideas en Internet:
LEGO.com/classic



LEGO CLASSIC



10692




10693

10694



10696



10701

10700





CREATOR



31030



31031




31032




31033


3
IN
1

LEGO.com/creator




2x
4618852


4x
300426


4x
300226


2x
300126


4x
4558954



2x
4548180


2x
366026


4x
4541455


2x
4189064


2x
6007896


2x
329826


2x
6092585


2x
302326


2x
302226


2x
4225201


2x
4297713


1x
247926


3x
4619599


3x
621528


4x
302228


1x
4583718


4x
4647553


1x
4617799


4x
6096995


3x
4142898



6x
3005740


3x
3005741


4x
306544


3x
3005748


8x
4579659


1x
4541414


4x
4164022


4x
4220632


4x
4165967


2x
4621548


4x
306540


3x
4244362


5x
622740


2x
6092599


2x
4158355


1x
4180540


8x
4121739


4x
4153826


4x
4118828


4x
4118829


4x
4251969


4x
4625027


12x
4651903


4x
4655173


4x
4625024


2x
6070777


4x
4619524


1x
4654448



Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor
LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346