



40236



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.






AVERTISSEMENT :
RISQUE D'ÉTOUFFEMENT.

Le jouet contient des petites pièces ainsi qu'une petite boule. Il ne convient pas aux enfants de moins de 3 ans.



ADVERTENCIA:
PELIGRO DE ASFIXIA.


Juguete que contiene partes pequeñas y una pelota pequeña. No recomendado para niños menores de 3 años.



1x

1x


1





4x

2



4





2x





2x

3







4



5





5



6



6





1






2







3




4





5





1



2



10



3




4






1





2








3




4





1






4x



5x

2






2x





1x


3






4








5






6






1



2





2x


3






1x


4





2x

5





6





1x

7





1x






1x

8






9




10





1x


11





2x

12





13






2x

14



2x



15





16


1



2



3



4




5



6



17







Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346

