



CITY

60134




 [LEGO.com/city](https://www.lego.com/city)



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.







AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.
Le jouet contient des petites pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants de moins de 3 ans.





ADVERTENCIA: PELIGRO DE ASFIXIA.
Juguete que contiene partes pequeñas y una pelota pequeña.
No recomendado para niños menores de 3 años.







1







2




3






4




6



5




6



7



8





1x


1





2x

2




1x



2x


3





1x


4





2x

5





1x




1x

6







1x

1





2x

2






1x

3



1x

4






2x

5







6



7







 1x 306201	 1x 6155407	 1x 663601	 1x 6054438	 1x 6151569	 1x 6123730	 1x 6000294	 1x 6102882
 1x 6139552	 1x 6146519	 1x 6057505	 1x 6066342	 1x 6103171	 1x 6153321	 1x 6142823	 1x 6029933
 1x 6154171	 1x 302101	 1x 6147214	 1x 4140585	 1x 6153221	 1x 6100203	 1x 6092833	 1x 6144805
 1x 6018511	 1x 4141607	 1x 4107623	 1x 302221	 1x 6112620	 1x 6105708	 1x 4527065	 2x 6054554
 1x 393801	 1x 4141607	 1x 4107623	 1x 4558856	 1x 6039464	 1x 6153328	 1x 6093260	 1x 3005744
 1x 300401	 1x 395701	 1x 459921	 1x 4567909	 1x 6154803	 1x 6153335	 1x 6155416	 1x 6047056
 1x 393701	 1x 302001	 1x 6029690	 1x 9341	 1x 4570043	 1x 6153341	 1x 6031019	 1x 6152450
 1x 6143141				 1x 6125384	 1x 4256320		



1x
6153141



1x
6152683




1x
6153136



5x
249626



1x
6021678



1x
6022880



1x
6152085



1x
6155227



1x
6152800



1x
9339



1x
4517986



1x
379528



1x
6153139



1x
6155234



2x
4504382



1x
4223247



1x
374128



1x
6016059



1x
6153137



1x
6152679



1x
4653226



2x
6154086



1x
74040



1x
6115306



1x
6153138



1x
6153512



1x
6099599



1x
6020193



2x
243528



2x
4622574



1x
6153140



4x
6145160



2x
4516843



1x
460026



2x
243528



1x
4524098



1x
4626884



1x
4273743



1x
4548180



1x
383926



1x
302028



1x
6155586



2x
4162916



3x
4252437



1x
4508313



1x
4530129



1x
6096091



1x
6003002



1x
4221886



1x
4211235



1x
4271874



1x
4211201



2x
4211204



1x
6146924



2x
4221590



1x
6154202



2x
4211506



1x
6057487



1x
4211740



2x
4211373



2x
6028812



3x
4211395



2x
4211425



1x
4244627



2x
4211803



1x
4211397



1x
6003098



1x
4258308



1x
6154097



2x
4210633



1x
4289542



2x
4210884



1x
6146933



1x
4211065



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :



LEGO and the LEGO logo are trademarks of the/son des marques de commerce du/son marcas registradas de LEGO Group.

©2016 The LEGO Group. 6162539