







3182





1



2










1




2




3




4







5




1



2



3



6



1



2



3



4



7






1




2



3



4



5




6



7



8




9




10



11




12



13



14



15





1




2



3



4



5



6



7




8



9



10




11






1




2




3




4



5



6




7



8







CITY



3177



3178



3179



3180



3181



3182



CITY



4209



4208



4427



www.LEGOclub.com



LEGO® Club Email



LEGO® Club Magazine



www.LEGO.com

SIGN UP ONLINE!

www.LEGOclub.com

LEGO and the LEGO logo are trademarks of the LEGO Group. ©2010, 2011 The LEGO Group. 6012191



00800 5346 5555*



1-866-534-6258 • 1-877-518-5346

US & Canada only

Canada seulement

- * Freephone. Mobile charges may apply.
- * Numéro sans frais. Des frais peuvent s'appliquer avec les téléphones cellulaires.
- * Gebührenfrei, Kosten für Anrufe aus Mobilfunknetzen können abweichen.
- * Gratis telefonnummer vanaf vaste lijn.
- * Det er et gratis nummer, når du ringer fra fasttelefon.
- * Det är gratis, när du ringer från en fast telefon.
- * Numéro sans frais. Des frais peuvent s'appliquer avec les téléphones portables.